


## Intonacatrice MK 20 - 230V completa - Quadro elettrico



### Détails des pièces

Pos.	Référence	Désignation
1	K200054	Quadro elettrico a pulsanti completo MK 20
2	K000014	
3	90731	Pulsante a 3 posizioni
4	30362	Porta etichette
5	K008522	
6	K200016	
7	K000021	
8	K200007	
9	K100318	
10	K100218	
11	C23411	11
12	30023	Spina elettrica 2P + T gomma
13	90601	Premistoppa spirale nero da 11

<b>Pos.</b>	<b>Référence</b>	<b>Désignation</b>
14	11622	Premistoppa plastica nero M 20
15	1002837	Premistoppa a tenuta ermetica PG 09