


TURBISOL 200 blowing machine - Chassis



Détails des pièces

Pos.	Référence	Désignation
1	C21971	TURBISOL 164 foam filter holder
2	12261	Ø22 M5 x 10 outer threaded plastic thumb wheel
3	13989	TURBISOL 164 turbine foam filter
4	C21498	Turbine door for TURBISOL 164/2 blowing machine
5	C21495	5
6	90157	M6 x 16 cylindrical head screw - CP 60
7	80259	Ø 6 medium washer
8	13536	Double turbine box gasket for TURBISOL 164/2
9	13537	TURBISOL 164/2 turbine gasket
10	13556	1-stage turbine - 230V
11	C21500	Turbine flange for TURBISOL 164/2
12	90151	8 x 10 cylindrical head screw
13	80260	ø 8 inox medium washer

Pos.	Référence	Désignation
14	C21494	Air box for TURBISOL 164/2 blowing machine
15	13632	M 20 grey rubber cable gland
16	11964	H05VVF 4G1 grey electrical cable by the metre
17	30040	Nickel plated watertight cable gland of 11 CEM
18	11916	Blowing machine insulating cover 3 p + T
19	11911	Blowing machine male insert 3 p + T
20	11752	Worm gear clamp 50 x 70 x 9
21	12216	Blowing machine hose Ø 48 x Length 75 mm
22	C22960	22
23	C22912	23
24	30145	Ø 40 x 20 M10 stop
25	80261	ø 10 inox medium washer
26	13981	M 10 nylstop inox nut
27	14539	THEF 6 x 20 screw
28	30273	THEF 8 x 20 screw
29	C22893	
30	80003	Ø400 complete wheel with shaft of 25 for 100TH, MPE 300
31	90282	Ø25 chromed clip
32	14721	Transmission protection crankcase for blowing machine TURBISOL 200
33	80470	8 x 20 cylindrical head screw